

TOUCH PANEL QUICK START GUIDE

Connect to the Room System

To show content on the display(s):

Connect the provided HDMI cable to your device.




To access the room's camera and microphone for video conferencing:

Connect the provided USB-A cable to your device.



To access the room's speakers to play audio:

Select **Crestron** as the system audio output on your device.



The source tab allows you to select a source to be displayed

The camera tab allows you to preview and control cameras manually

The mics tab allows you to adjust volume and mute/unmute mics

Push to turn the system off

The menu tab allows you to navigate to different pages of the touch panel

The utilities tab allows access to:


- Display power
- Show video
- Screen control
- HDCP control

Shows the current state of display
If off is selected, content is still being captured in a Classroom Capture

Volume control for microphones

When a device is connected using the provided cables, "Laptop" will automatically be selected

Volume control for the selected source



Classroom recording occurs only when requested by the Instructor

Scheduled recordings will automatically start and stop. Once started, recordings can be paused and resumed on the touch panel.

To request Classroom Capture contact the IT Service Center or visit the OIT website:

<https://oit.colorado.edu/services/teaching-learning-applications/classroom-capture/>

If you require expedited technical assistance with the A/V system, please scan the QR code to fill out a Problem Report.



You can also call (303) 735-4357 or "5-4357" from the in-room phone.



Learning Spaces Technology

UNIVERSITY OF COLORADO BOULDER

OFFICE OF INFORMATION TECHNOLOGY